

Studio Armrest Installation

1. Flip the chair upside down and rest the seat pan on a flat surface such as another chair.
2. Find 3 prong nuts (holes) on either the side of the seat ply and cut the lining fabric to expose the nuts.
3. Clean out these prongs to ensure there is no fabric, wood or staples obstructing them.
4. Place washers in position: metal one on front and 2 x plastic ones on the back/lower prongs.
5. Place arm bracket on top of washers with the thick part of the arm pad facing the front of the chair.
6. Insert bolts: 25mm bolt in front and 2 x 30mm bolts in back/lower side of seat. Tighten bolts.