



**Dry Erase / Whiteboard Marker
Storage Recommendations
for Maximum Performance
and Long Lasting Colour**



Storing tips down
keeps the ink
ready to go



Storing on their
side keeps the ink
evenly dispersed
in the marker



Storing tips up
keeps the ink
away from
the tip

If stored incorrectly or for long periods - you may need to invert the markers and allow the ink to run back to the tip